


HOW TO BUILD A 12X8 SHED



With Illustrations, Drawings & Step By Step Details

Note: This is a sample plan from RyanShedPlans. <u>All other plans in our collection</u> goes *indepth* with <u>more details</u>, more instructions, complete material lists and illustrated photos...

TABLE OF CONTENTS

OVERVIEW:	3
Materials & Cutting Lists:	4
DRAWINGS, ELEVATIONS & DETAILS	8
Step By Step Instructions	17
Step A: Build the Foundation & Floor Frame	17
Step B: Frame the Walls	19
Step C: Frame the Roof	20
Step D: Build the Gable Overhangs	22
Step E: Install the Fascia, Sheathing & Roofing	22
Step F: Install the Soffits & Siding	24
Step G: Build & Install the Doors	25
Step H: Build & Install the Windows & Trim	27
Step I: Build the Ramp (Optional)	28

OVERVIEW:

This 8×12 -ft. shed features a simple gable roof, double doors, and side and rear windows for natural lighting. With full-height walls and doors, there's ample room for storing large items or creating a comfortable work space. An optional wood ramp helps in moving lawn mowers and other heavy equipment.

The shed's simple construction makes it especially adaptable for different uses. For example, you can easily frame in additional windows—to use the shed as a workshop or potting shed—or omit all of the windows and devote the space entirely to secure storage.

The finish materials for the basic shed also are true to its name: asphalt roof shingles, plywood siding, and simple trim details are appropriately practical for this classic outbuilding design. You can purchase prehung doors or build your own using the project plans.

MATERIALS & CUTTING LISTS:

Materials					
Description	Quantity	y/Size	Material		
Foundation					
Drainage			Compactible		
material	1.4 cu.	yd.	gravel		
			4 × 4 treated		
Skids	3 @ 12	2'-0"	timbers		
Floor Framing					
			2 × 6 pressure-		
Rim joists	2 @ 12	2'-0"	treated		
-			2 × 6 pressure-		
joists	10 @ 8	3'-0"	treated		
			3/4" tongue-&-		
Floor			groove extgrade		
sheathing	8'		plywood		
			3" × 3" × 3" ×		
Joist clip			16-gauge		
angles	20		galvanized		
	Wa	all Framing	-		
Bottom	2 @ 12'-0", 1				
plates	@ 8'-0"	2×4			
	4 @ 12'-0", 4				
Top plates	@ 8'-0"	2 × 4			
Studs	40 @ 92 5/8"	2 × 4			
	2 @ 10'-0'', 2				
Headers	@ 6'-0"	2 × 6			
Header	1 @ 9'-0", 1 @	1/2" plywood	l—5"		
spacers	6'-0"	wide			
	Gable	Wall Framii	ng		
Top plates	2 @ 8'-0"	2 × 4			
Studs	2 @ 8'-0"	2 × 4			
		of Framing			
Rafters	22 @ 6'-0"	2 × 6			
Metal					
anchors—					
rafters	10, with nails	Simpson H1			
Rafter ties	3 @ 8'-0"	2 × 4			
Ridge board	1 @ 14'-0"	2 × 8			
Lookouts	1 @ 8'-0"	2 × 6			

	1 @ 8'-0", 2 @		
Subfascia	· ·	2 × 6	
Soffit nailers	3 @ 8'-0"	2 × 6 2 × 2	
		rior Finishes	
Plywood 10 sheets @ 4 5/8" texture 1-11 plywood siding,			
siding	× 9'	p.y e.ag,	
		grooves 8" o.c.	
		g. con co	
	2 pieces @ 8 ft.	Galvanized-18	
Z-		gauge	
Wall &			
corner	10 @ 10'-0"	1 × 4 S4S cedar	
Fascia	8 @ 8'-0"	1 x 8 S4S cedar	
Plywood	2 sheets @ 4 ×	3/8" cedar or fir	
soffits	8'	plywood	
		Louver with bug	
Soffit	4 @ 4 × 12"	screen	
Flashing			
(door/wi		Galvanized—18	
		Roofing	
Roof	6 sheets @ 4 ×	1/2" extgrade	
sheathing	8'	plywood	
Asphalt		250# per square	
shingles	150 sq. ft.	(min.)	
15# building			
paper	150 sq. ft.		
Metal drip	2 @ 14'-0", 4		
edge	@ 6'-0"	Galvanized metal	
Roof vents			
(optional)	2 units		
	T	Door	
		3/4 × 4 1/4"	
_	2 @ 8'-0", 1 @	(actual) S4S	
Frame	6'-0"	cedar	
	2 @ 8'-0", 1 @		
Stops	6'-0"	1 × 2 S4S cedar	
Panel	40 0 0 0 0"	1 × 6 T&G V-joint	
material	12 @ 8'-0"	S4S cedar	
Z-brace	4 @ 6'-0"	1 × 6 S4S cedar	
Construction			
adhesive	1 tube		
Fortant or Cate	2 @ 8'-0", 1 @	1 4 646 and an	
Exterior trim	6'-0"	1 × 4 S4S cedar	


Interior trim	2 @ 8'-0", 1 @			
(optional)	•	1 × 2 S4S cedar		
Strap hinges		Exterior hinges		
1 5		Windows		
	3/4 × 4 1/4"			
		(actual) S4S cedar		
Frames	5 @ 6'-0"			
Mullion	1 @ 3'-0"	2 × 4 S4S cedar		
Stops	10 @ 6'-0" 1 x 2 S4S cedar			
Glazing tape	30 linear ft.	Glazing tape		
	3 pieces—field	1/4" clear, tempered		
Window				
Exterior trim	5 @ 8'-0"	1 × 4 S4S cedar		
Interior trim				
	Ram	p (Optional)		
		2 × 8 pressure-		
Pads	2 @ 6'-0"	treated		
		2 × 8 pressure-		
Stringers	1 @ 8'-0"	treated		
		2 × 4 pressure-		
Decking	7 @ 6'-0"	treated		
	F	asteners		
16d common				
nails	16 lbs.			
10d common				
nails	1 lb.			
10d				
galvanized				
casing nails	1 lb.			
8d common	1/2 lb			
nails	1/2 lb. 3 lbs.			
8d box nails	o ino.			
8d				
galvanized box nails	1 1/2 lbs.			
8d	1 1/2 103.			
galvanized				
finish nails	7 lbs.			
3d	7 103.			
galvanized				
box nails	1/4 lb.			
7/8"	.,			
galvanized				
roofing nails	2 lbs			
. Joining Hallo	_ :23			

1 1/2" joist	
hanger nails	80 nails
1 1/4" wood	
screws	70 screws
3 1/2" deck	
screws	12 screws
3" deck	
screws	50 screws
2 1/2"	
deck	40 screws
1 1/4"	
deck	30 screws
Silicon	
e- latex	1 tube

DRAWINGS, ELEVATIONS & DETAILS


FRONT FRAMING ELEVATION

LEFT SIDE FRAMING ELEVATION




FRONT FRAMING ELEVATION


LEFT SIDE FRAMING ELEVATION




RIGHT SIDE FRAMING ELEVATION




BUILDING SECTION





RAFTER TEMPLATE




FLOOR FRAMING PLAN












HORIZONTAL TRIM DETAIL







GABLE OVERHANG DETAIL




EAVE DETAIL




WINDOW JAMB DETAIL



RAMP DETAIL (OPTIONAL)







If you want 12,000 more shed plans with details, drawings, elevations and step by step instructions like this, <u>visit Ryan's</u>
Shed Plans now and get started on your next shed!

STEP BY STEP INSTRUCTIONS

BUILDING THE BASIC SHED

STEP A: BUILD THE FOUNDATION & FLOOR FRAME

- 1. Excavate the building site and add a 4" layer of compactible gravel. If desired, add an extension to the base for the optional wood ramp. Tamp the gravel thoroughly, making sure it is flat and level.
- 2. Cut three 4×4 treated timber skids at 144". Arrange and level the skids on the gravel bed, following the FLOOR FRAMING PLAN.
- 3. Cut two 2×6 rim joists at 144" and ten joists at 93". Mark the joist layout onto the rim joists, following the plan. Assemble frame with 16d galv. common nails; be sure to check each joist for crowning and install it with the crowned edge up.
- 4. Set the floor frame on top of the skids and measure the diagonals to make sure it's square. Install metal clip angles at each joist along the two outer skids, using $1\,1/2$ " joist hanger nails and 16d galv. common nails, and toenail each joist to the center skid with 16d galv. nails.
- 5. Install the tongue-and-groove floor sheathing, starting with a full sheet at one corner of the frame. Use 8d galv. nails driven every 6" along the edges and every 12" in the field.

Thank You for previewing this eBook

You can read the full version of this eBook in different formats:

- HTML (Free /Available to everyone)
- PDF / TXT (Available to V.I.P. members. Free Standard members can access up to 5 PDF/TXT eBooks per month each month)
- Epub & Mobipocket (Exclusive to V.I.P. members)

To download this full book, simply select the format you desire below

